

OEM/ODM

SWITCH AND SOCKET

2024

Product Catalog

SWITCH
SOCKET

Laboratory

Professional testing equipment to protect the quality of
Products so that we will give you the best things.



Our Certificate



Manufacturing and Monitoring systems is to guarantee of the product quality.
Establish professional laboratory and product quality
testing centers is to reach the domestic and international standards.
We are always adhere certification standard such as ISO9001,
CCC national standard.



1.5°
Ultra small swing angle

2.5mm
Ultra-short key travel

6.0mm
The overall thickness



Ultra thin

Provide the global home with great idea and create a beautiful home,
its electricalaccessories not only excellent in function.
but also add unlimited fun and personalized features for your living space,
we brought together singularity withinspiration, will create a unique household environment for you.

German Quality

T5
SERIES



Ultra thin
The Beauty Of Thinness

Glass

White Gold
Grey Black Blue



SWITCH
SOCKET

Provide the global home with great idea and create a beautiful home,
its electricalaccessories not only excellent in function.
but also add unlimited fun and personalized features for your living space,
we brought together singularity withinspiration, will create a unique household environment for you.

T5 | White series — Ultra thin

T5-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T5-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T5-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T5-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T5-05
Doorbell Switch



T5-06
MF Big Switched Socket
With Neon



T5-07
MF Switched Socket
With Neon



T5-08
MF Switched Socket
With Neon+2USB



T5-09
MF Switched Socket
With Neon+USB+ Type-C



T5-10
5 pin MF Big Switched
Socket With Neon



T5-11
5 pin MF Switched Socket
With Neon



T5-12
13A Big Switched Socket
With Neon



T5-13
13A Switched Socket
With Neon



T5-14
13A Switched Socket
With Neon+2USB



T5-15
13A Switched Socket
With Neon+USB+ Type-C



T5-16
15A Big Switched Socket
With Neon



T5-17
15A Switched Socket
With Neon



T5-18
2 Pole Switched Socket



T5-19
4 Pole Switched Socket



T5-20
20A Switch With Neon



T5-21
45A Switch With Neon



T5-22
Two Pole Socket



T5-23
MF Socket



T5-24
13A Socket



T5-25
Four Pole Socket



T5-26
5 pin MF Socket



T5-27
5 pin MF Socket+2USB



T5-28
5 pin MF Socket
+USB+2 Type-C



T5-29
5 pin MF Switched Socket
With Neon+2 USB



T5-30
5 pin MF Switched Socket
With Neon+USB+Type-C



T5-31
USB+Type-C Socket



T5-32
Double USB+Type-C
Socket



T5-33
25A Switch With Neon



T5-34
45A Switch With Neon



T5-35
Germany Socket



T5-36
French Socket

T5 | White series — SWITCH & SOCKET



T5-37
Europe socket



T5-38
Satellite Socket



T5-39
TV Socket



T5-40
TEL Socket
T5-41
Computer Socket

T5-42
TV+TEL Socket

T5-43
TV+ Computer Socket
T5-44
Double Computer Socket

T5-45
Satellite+TV Socket
T5-46
Satellite+Computer Socket

T5-47
Dimmer Switch
T5-48
Speed Control Switch

T5-49
Voice Control swith
T5-50
Touch Delay Swith

T5-51
Human Body Sensor
Switch

T5-52
Human-induced Foot Lamp

T5-53
86 Blank Plate
T5-70
146 Blank Plate

T5-54
Double 13A Big Switched Socket
With Neon

T5-55
Double 13A Switched Socket
With Neon

T5-56
Double 13A Switched Socket
With Neon+2USB

T5-57
Double 13A Switched Socket
With Neon+USB+ Type-C

T5-58
Double MF Big Switched Socket
With Neon

T5-59
Double MF Switched Socket
With Neon

T5-60
Double MF Switched Socket
With Neon+2USB

T5-61
Double MF Switched Socket
With Neon+USB+ Type-C

T5-62
Double 5 pin MF Big Switched Socket
With Neon

T5-63
Double 5 pin MF Switched Socket
With Neon

T5-64
Double 5 pin MF Switched Socket
With Neon+2USB

T5-65
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T5-66
Double 13A Socket

T5-67
Double 13A Socket

T5-68
Cooker Unit

T5-69
45A Switch With Neon

T5 | Gold series — Ultra thin



T5-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T5-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T5-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T5-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T5-05
Doorbell Switch



T5-06
MF Big Switched Socket
With Neon



T5-07
MF Switched Socket
With Neon



T5-08
MF Switched Socket
With Neon+2USB



T5-09
MF Switched Socket
With Neon+USB+ Type-C



T5-10
5 pin MF Big Switched
Socket With Neon



T5-11
5 pin MF Switched Socket
With Neon



T5-12
13A Big Switched Socket
With Neon



T5-13
13A Switched Socket
With Neon



T5-14
13A Switched Socket
With Neon+2USB



T5-15
13A Switched Socket
With Neon+USB+ Type-C



T5-16
15A Big Switched Socket
With Neon



T5-17
15A Switched Socket
With Neon



T5-18
2 Pole Switched Socket



T5-19
4 Pole Switched Socket



T5-20
20A Switch With Neon



T5-21
45A Switch With Neon



T5-22
Two Pole Socket



T5-23
MF Socket



T5-24
13A Socket



T5-25
Four Pole Socket



T5-26
5 pin MF Socket



T5-27
5 pin MF Socket+2USB



T5-28
5 pin MF Socket
+USB+2 Type-C



T5-29
5 pin MF Switched Socket
With Neon+2 USB



T5-30
5 pin MF Switched Socket
With Neon+USB+Type-C



T5-31
USB+Type-C Socket



T5-32
Double USB+Type-C
Socket



T5-33
25A Switch With Neon



T5-34
45A Switch With Neon



T5-35
Germany Socket



T5-36
French Socket

T5 | Gold series — SWITCH & SOCKET



T5-37
Europe socket



T5-38
Satellite Socket



T5-39
TV Socket



T5-40
TEL Socket
T5-41
Computer Socket

T5-42
TV+TEL Socket

T5-43
TV+ Computer Socket
T5-44
Double Computer Socket

T5-45
Satellite+TV Socket
T5-46
Satellite+Computer Socket

T5-47
Dimmer Switch
T5-48
Speed Control Switch

T5-49
Voice Control swith
T5-50
Touch Delay Swith

T5-51
Human Body Sensor
Switch

T5-52
Human-induced Foot Lamp

T5-53
86 Blank Plate
T5-70
146 Blank Plate

T5-54
Double 13A Big Switched Socket
With Neon

T5-55
Double 13A Switched Socket
With Neon

T5-56
Double 13A Switched Socket
With Neon+2USB

T5-57
Double 13A Switched Socket
With Neon+USB+ Type-C

T5-58
Double MF Big Switched Socket
With Neon

T5-59
Double MF Switched Socket
With Neon

T5-60
Double MF Switched Socket
With Neon+2USB

T5-61
Double MF Switched Socket
With Neon+USB+ Type-C

T5-62
Double 5 pin MF Big Switched Socket
With Neon

T5-63
Double 5 pin MF Switched Socket
With Neon

T5-64
Double 5 pin MF Switched Socket
With Neon+2USB

T5-65
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T5-66
Double 13A Socket

T5-67
Double 13A Socket

T5-68
Cooker Unit

T5-69
45A Switch With Neon

T5 | Gray series — Ultra thin



T5-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T5-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T5-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T5-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T5-05
Doorbell Switch



T5-06
MF Big Switched Socket
With Neon



T5-07
MF Switched Socket
With Neon



T5-08
MF Switched Socket
With Neon+2USB



T5-09
MF Switched Socket
With Neon+USB+ Type-C



T5-10
5 pin MF Big Switched
Socket With Neon



T5-11
5 pin MF Switched Socket
With Neon



T5-12
13A Big Switched Socket
With Neon



T5-13
13A Switched Socket
With Neon



T5-14
13A Switched Socket
With Neon+2USB



T5-15
13A Switched Socket
With Neon+USB+ Type-C



T5-16
15A Big Switched Socket
With Neon



T5-17
15A Switched Socket
With Neon



T5-18
2 Pole Switched Socket



T5-19
4 Pole Switched Socket



T5-20
20A Switch With Neon



T5-21
45A Switch With Neon



T5-22
Two Pole Socket



T5-23
MF Socket



T5-24
13A Socket



T5-25
Four Pole Socket



T5-26
5 pin MF Socket



T5-27
5 pin MF Socket+2USB



T5-28
5 pin MF Socket
+USB+2 Type-C



T5-29
5 pin MF Switched Socket
With Neon+2 USB



T5-30
5 pin MF Switched Socket
With Neon+USB+Type-C



T5-31
USB+Type-C Socket



T5-32
Double USB+Type-C
Socket



T5-33
25A Switch With Neon



T5-34
45A Switch With Neon



T5-35
Germany Socket



T5-36
French Socket

T5 | Gray series — SWITCH & SOCKET



T5-37
Europe socket



T5-38
Satellite Socket



T5-39
TV Socket



T5-40
TEL Socket
T5-41
Computer Socket

T5-42
TV+TEL Socket

T5-43
TV+ Computer Socket
T5-44
Double Computer Socket

T5-45
Satellite+TV Socket
T5-46
Satellite+Computer Socket

T5-47
Dimmer Switch
T5-48
Speed Control Switch

T5-49
Voice Control swith
T5-50
Touch Delay Swith

T5-51
Human Body Sensor
Switch

T5-52
Human-induced Foot Lamp

T5-53
86 Blank Plate
T5-70
146 Blank Plate

T5-54
Double 13A Big Switched Socket
With Neon

T5-55
Double 13A Switched Socket
With Neon

T5-56
Double 13A Switched Socket
With Neon+2USB

T5-57
Double 13A Switched Socket
With Neon+USB+ Type-C

T5-58
Double MF Big Switched Socket
With Neon

T5-59
Double MF Switched Socket
With Neon

T5-60
Double MF Switched Socket
With Neon+2USB

T5-61
Double MF Switched Socket
With Neon+USB+ Type-C

T5-62
Double 5 pin MF Big Switched Socket
With Neon

T5-63
Double 5 pin MF Switched Socket
With Neon

T5-64
Double 5 pin MF Switched Socket
With Neon+2USB

T5-65
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T5-66
Double 13A Socket

T5-67
Double 13A Socket

T5-68
Cooker Unit

T5-69
45A Switch With Neon

T5 | Black series — Ultra thin



T5-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T5-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T5-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T5-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T5-05
Doorbell Switch



T5-06
MF Big Switched Socket
With Neon



T5-07
MF Switched Socket
With Neon



T5-08
MF Switched Socket
With Neon+2USB



T5-09
MF Switched Socket
With Neon+USB+ Type-C



T5-10
5 pin MF Big Switched
Socket With Neon



T5-11
5 pin MF Switched Socket
With Neon



T5-12
13A Big Switched Socket
With Neon



T5-13
13A Switched Socket
With Neon



T5-14
13A Switched Socket
With Neon+2USB



T5-15
13A Switched Socket
With Neon+USB+ Type-C



T5-16
15A Big Switched Socket
With Neon



T5-17
15A Switched Socket
With Neon



T5-18
2 Pole Switched Socket



T5-19
4 Pole Switched Socket



T5-20
20A Switch With Neon



T5-21
45A Switch With Neon



T5-22
Two Pole Socket



T5-23
MF Socket



T5-24
13A Socket



T5-25
Four Pole Socket



T5-26
5 pin MF Socket



T5-27
5 pin MF Socket+2USB



T5-28
5 pin MF Socket
+USB+2 Type-C



T5-29
5 pin MF Switched Socket
With Neon+2 USB



T5-30
5 pin MF Switched Socket
With Neon+USB+Type-C



T5-31
USB+Type-C Socket



T5-32
Double USB+Type-C
Socket



T5-33
25A Switch With Neon



T5-34
45A Switch With Neon



T5-35
Germany Socket



T5-36
French Socket

T5 | Black series — SWITCH & SOCKET



T5-37
Europe socket



T5-38
Satellite Socket



T5-39
TV Socket



T5-40
TEL Socket
T5-41
Computer Socket

T5-42
TV+TEL Socket

T5-43
TV+ Computer Socket
T5-44
Double Computer Socket

T5-45
Satellite+TV Socket
T5-46
Satellite+Computer Socket

T5-47
Dimmer Switch
T5-48
Speed Control Switch

T5-49
Voice Control swith
T5-50
Touch Delay Swith

T5-51
Human Body Sensor
Switch

T5-52
Human-induced Foot Lamp

T5-53
86 Blank Plate
T5-70
146 Blank Plate

T5-54
Double 13A Big Switched Socket
With Neon

T5-55
Double 13A Switched Socket
With Neon

T5-56
Double 13A Switched Socket
With Neon+2USB

T5-57
Double 13A Switched Socket
With Neon+USB+ Type-C

T5-58
Double MF Big Switched Socket
With Neon

T5-59
Double MF Switched Socket
With Neon

T5-60
Double MF Switched Socket
With Neon+2USB

T5-61
Double MF Switched Socket
With Neon+USB+ Type-C

T5-62
Double 5 pin MF Big Switched Socket
With Neon

T5-63
Double 5 pin MF Switched Socket
With Neon

T5-64
Double 5 pin MF Switched Socket
With Neon+2USB

T5-65
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T5-66
Double 13A Socket

T5-67
Double 13A Socket

T5-68
Cooker Unit

T5-69
45A Switch With Neon

T3 series



Ultra thin

Provide the global home with great idea and create a beautiful home,
its electricalaccessories not only excellent in function.
but also add unlimited fun and personalized features for your living space,
we brought together singularity withinspiration, will create a unique household environment for you.

White Gold Grey Black

German Quality

T3 White series Ultra thin

T3-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch

T3-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T3-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T3-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T3-05
Doorbell Switch



T3-06
MF Switched Socket
With Neon



T3-07
MF Switched Socket
With Neon+2USB



T3-08
MF Switched Socket
With Neon+USB+ Type-C



T3-09
15A Switched Socket
With Neon



T3-10
5 pin MF Switched Socket
With Neon



T3-11
13A Switched Socket
With Neon



T3-12
13A Switched Socket
With Neon+2USB



T3-13
13A Switched Socket
With Neon+USB+ Type-C



T3-14
2 Pole Switched Socket



T3-15
4 Pole Switched Socket



T3-16
20A Switch With Neon



T3-17
45A Switch With Neon



T3-18
Two Pole Socket



T3-19
MF Socket



T3-20
13A Socket



T3-21
Four Pole Socket



T3-22
5 pin MF Socket



T3-23
5 pin MF Socket+2USB



T3-24
5 pin MF Socket
+USB+2 Type-C



T3-25
5 pin MF Switched Socket
With Neon+2 USB



T3-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T3-27
USB+Type-C Socket



T3-28
Double USB+Type-C
Socket



T3-29
25A Switch With Neon



T3-30
45A Switch With Neon

T3 White series Ultra thin



T3-31
Germany socket



T3-32
French socket



T3-33
Europe socket



T3-34
Satellite Socket



T3-35
TV Socket



T3-36
TEL Socket
T3-37
Computer Socket



T3-38
TV+TEL Socket



T3-39
TV+ Computer Socket



T3-40
Double Computer Socket



T3-41
Satellite+TV Socket
T3-42
Satellite+Computer Socket

T3-43
Dimmer Switch
T3-44
Speed Control Switch

T3-45
Voice Control Swith
T3-46
Touch Delay Swith

T3-47
Human Body Sensor
Switch

T3-48
Human-induced Foot Lamp

T3-49
86 Blank Plate
T3-62
146 Blank Plate

T3-50
Double 13A Switched Socket
With Neon

T3-51
Double 13A Switched Socket
With Neon+2USB

T3-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T3-53
Double 13A Socket

T3-54
Double MF Switched Socket
With Neon

T3-55
Double MF Switched Socket
With Neon+2USB

T3-56
Double MF Switched Socket
With Neon+USB+ Type-C

T3-57
Cooker Unit

T3-58
Double 5 pin MF Switched Socket
With Neon

T3-59
Double 5 pin MF Switched Socket
With Neon+2USB

T3-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T3-61
45A Switch With Neon

T3 | Gold series — Ultra thin



T3-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T3-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T3-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T3-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T3-05
Doorbell Switch



T3-06
MF Switched Socket
With Neon



T3-07
MF Switched Socket
With Neon+2USB



T3-08
MF Switched Socket
With Neon+USB+ Type-C



T3-09
15A Switched Socket
With Neon



T3-10
5 pin MF Switched Socket
With Neon



T3-11
13A Switched Socket
With Neon




T3-12
13A Switched Socket
With Neon+2USB



T3-13
13A Switched Socket
With Neon+USB+ Type-C



T3-14
2 Pole Switched Socket



T3-15
4 Pole Switched Socket



T3-16
20A Switch With Neon



T3-17
45A Switch With Neon



T3-18
Two Pole Socket



T3-19
MF Socket



T3-20
13A Socket



T3-21
Four Pole Socket



T3-22
5 pin MF Socket



T3-23
5 pin MF Socket+2USB



T3-24
5 pin MF Socket
+USB+2 Type-C



T3-25
5 pin MF Switched Socket
With Neon+2 USB



T3-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T3-27
USB+Type-C Socket



T3-28
Double USB+Type-C
Socket



T3-29
25A Switch With Neon



T3-30
45A Switch With Neon

T3 | Gold series — Ultra thin



T3-31
Germany socket



T3-32
French socket



T3-33
Europe socket



T3-34
Satellite Socket



T3-35
TV Socket



T3-36
TEL Socket
T3-37
Computer Socket



T3-38
TV+TEL Socket



T3-39
TV+ Computer Socket



T3-40
Double Computer Socket



T3-41
Satellite+TV Socket
T3-42
Satellite+Computer Socket

T3-43
Dimmer Switch
T3-44
Speed Control Switch

T3-45
Voice Control Swith
T3-46
Touch Delay Swith

T3-47
Human Body Sensor
Switch

T3-48
Human-induced Foot Lamp

T3-49
86 Blank Plate
T3-62
146 Blank Plate

T3-50
Double 13A Switched Socket
With Neon

T3-51
Double 13A Switched Socket
With Neon+2USB

T3-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T3-53
Double 13A Socket

T3-54
Double MF Switched Socket
With Neon

T3-55
Double MF Switched Socket
With Neon+2USB

T3-56
Double MF Switched Socket
With Neon+USB+ Type-C

T3-57
Cooker Unit

T3-58
Double 5 pin MF Switched Socket
With Neon

T3-59
Double 5 pin MF Switched Socket
With Neon+2USB


T3-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T3-61
45A Switch With Neon


T3 Gray series — Ultra thin




T3-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T3-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T3-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T3-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T3-05
Doorbell Switch



T3-06
MF Switched Socket
With Neon



T3-07
MF Switched Socket
With Neon+2USB



T3-08
MF Switched Socket
With Neon+USB+ Type-C



T3-09
15A Switched Socket
With Neon



T3-10
5 pin MF Switched Socket
With Neon



T3-11
13A Switched Socket
With Neon




T3-12
13A Switched Socket
With Neon+2USB



T3-13
13A Switched Socket
With Neon+USB+ Type-C



T3-14
2 Pole Switched Socket



T3-15
4 Pole Switched Socket



T3-16
20A Switch With Neon



T3-17
45A Switch With Neon



T3-18
Two Pole Socket



T3-19
MF Socket



T3-20
13A Socket



T3-21
Four Pole Socket



T3-22
5 pin MF Socket



T3-23
5 pin MF Socket+2USB



T3-24
5 pin MF Socket
+USB+2 Type-C



T3-25
5 pin MF Switched Socket
With Neon+2 USB



T3-26
5 pin MF Switched Socket
With Neon+USB+Type-C




T3-27
USB+Type-C Socket



T3-28
Double USB+Type-C
Socket



T3-29
25A Switch With Neon



T3-30
45A Switch With Neon

T3 Gray series — Ultra thin



T3-31
Germany socket




T3-32
French socket



T3-33
Europe socket



T3-34
Satellite Socket



T3-35
TV Socket



T3-36
TEL Socket
T3-37
Computer Socket



T3-38
TV+TEL Socket



T3-39
TV+ Computer Socket



T3-40
Double Computer Socket



T3-41
Satellite+TV Socket
T3-42
Satellite+Computer Socket

T3-43
Dimmer Switch
T3-44
Speed Control Switch

T3-45
Voice Control Swith
T3-46
Touch Delay Swith

T3-47
Human Body Sensor
Switch

T3-48
Human-induced Foot Lamp

T3-49
86 Blank Plate
T3-62
146 Blank Plate

T3-50
Double 13A Switched Socket
With Neon

T3-51
Double 13A Switched Socket
With Neon+2USB

T3-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T3-53
Double 13A Socket

T3-54
Double MF Switched Socket
With Neon

T3-55
Double MF Switched Socket
With Neon+2USB

T3-56
Double MF Switched Socket
With Neon+USB+ Type-C

T3-57
Cooker Unit

T3-58
Double 5 pin MF Switched Socket
With Neon

T3-59
Double 5 pin MF Switched Socket
With Neon+2USB

T3-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T3-61
45A Switch With Neon

T3 | Black series — Ultra thin



T3-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T3-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T3-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T3-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T3-05
Doorbell Switch



T3-06
MF Switched Socket
With Neon



T3-07
MF Switched Socket
With Neon+2USB



T3-08
MF Switched Socket
With Neon+USB+ Type-C



T3-09
15A Switched Socket
With Neon



T3-10
5 pin MF Switched Socket
With Neon



T3-11
13A Switched Socket
With Neon



T3-12
13A Switched Socket
With Neon+2USB



T3-13
13A Switched Socket
With Neon+USB+ Type-C



T3-14
2 Pole Switched Socket



T3-15
4 Pole Switched Socket



T3-16
20A Switch With Neon



T3-17
45A Switch With Neon



T3-18
Two Pole Socket



T3-19
MF Socket



T3-20
13A Socket



T3-21
Four Pole Socket



T3-22
5 pin MF Socket



T3-23
5 pin MF Socket+2USB



T3-24
5 pin MF Socket
+USB+2 Type-C



T3-25
5 pin MF Switched Socket
With Neon+2 USB



T3-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T3-27
USB+Type-C Socket



T3-28
Double USB+Type-C
Socket



T3-29
25A Switch With Neon



T3-30
45A Switch With Neon

T3 | Black series — Ultra thin



T3-31
Germany socket



T3-32
French socket



T3-33
Europe socket



T3-34
Satellite Socket



T3-35
TV Socket



T3-36
TEL Socket
T3-37
Computer Socket



T3-38
TV+TEL Socket



T3-39
TV+ Computer Socket



T3-40
Double Computer Socket



T3-41
Satellite+TV Socket
T3-42
Satellite+Computer Socket

T3-43
Dimmer Switch
T3-44
Speed Control Switch

T3-45
Voice Control Swith
T3-46
Touch Delay Swith

T3-47
Human Body Sensor
Switch

T3-48
Human-induced Foot Lamp

T3-49
86 Blank Plate
T3-62
146 Blank Plate

T3-50
Double 13A Switched Socket
With Neon

T3-51
Double 13A Switched Socket
With Neon+2USB

T3-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T3-53
Double 13A Socket

T3-54
Double MF Switched Socket
With Neon

T3-55
Double MF Switched Socket
With Neon+2USB

T3-56
Double MF Switched Socket
With Neon+USB+ Type-C

T3-57
Cooker Unit

T3-58
Double 5 pin MF Switched Socket
With Neon

T3-59
Double 5 pin MF Switched Socket
With Neon+2USB

T3-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T3-61
45A Switch With Neon

F10
SERIES



Perfect Touch
Technical breakthrough

Breakthrough the traditional switch warping plate struture limitations

White Gold Grey Black

German Quality



SWITCH ON
A STYLISH LIFE

F10 White series

F10-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



F10-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



F10-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



F10-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



F10-05
Doorbell Switch



F10-06
MF Switched Socket
With Neon



F10-07
MF Switched Socket
With Neon+2USB



F10-08
MF Switched Socket
With Neon+USB+ Type-C



F10-09
15A Switched Socket
With Neon



F10-10
5 pin MF Switched Socket
With Neon



F10-11
13A Switched Socket
With Neon



F10-12
13A Switched Socket
With Neon+2USB



F10-13
13A Switched Socket
With Neon+USB+ Type-C



F10-14
2 Pole Switched Socket



F10-15
4 Pole Switched Socket



F10-16
20A Switch With Neon



F10-17
45A Switch With Neon



F10-18
Two Pole Socket



F10-19
MF Socket



F10-20
13A Socket



F10-21
Four Pole Socket



F10-22
5 pin MF Socket



F10-23
5 pin MF Socket+2USB



F10-24
5 pin MF Socket
+USB+2 Type-C



F10-25
5 pin MF Switched Socket
With Neon+2 USB



F10-26
5 pin MF Switched Socket
With Neon+USB+Type-C



F10-27
USB+Type-C Socket



F10-28
Double USB+Type-C
Socket



F10-29
25A Switch With Neon



F10-30
45A Switch With Neon



F10-31
Germany socket



F10-32
French socket



F10-33
Europe socket



F10-34
Satellite Socket



F10-35
TV Socket



F10-36
TEL Socket
F10-37
Computer Socket



F10-38
TV+TEL Socket



F10-39
TV+ Computer Socket



F10-40
Double Computer Socket



F10-41
Satellite+TV Socket
F10-42
Satellite+Computer Socket

F10-43
Dimmer Switch
F10-44
Speed Control Switch

F10-45
Voice Control Swith
F10-46
Touch Delay Swith

F10-47
Human Body Sensor
Switch

F10-48
Human-induced Foot Lamp

F10-49
86 Blank Plate
F10-62
146 Blank Plate

F10-50
Double 13A Switched Socket
With Neon

F10-51
Double 13A Switched Socket
With Neon+2USB

F10-52
Double 13A Switched Socket
With Neon+USB+ Type-C

F10-53
Double 13A Socket

F10-54
Double MF Switched Socket
With Neon

F10-55
Double MF Switched Socket
With Neon+2USB

F10-56
Double MF Switched Socket
With Neon+USB+ Type-C

F10-57
Cooker Unit

F10-58
Double 5 pin MF Switched Socket
With Neon

F10-59
Double 5 pin MF Switched Socket
With Neon+2USB

F10-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

F10-61
45A Switch With Neon

F10 Gold series



F10-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



F10-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



F10-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



F10-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



F10-05
Doorbell Switch



F10-06
MF Switched Socket
With Neon



F10-07
MF Switched Socket
With Neon+2USB



F10-08
MF Switched Socket
With Neon+USB+ Type-C



F10-09
15A Switched Socket
With Neon



F10-10
5 pin MF Switched Socket
With Neon



F10-11
13A Switched Socket
With Neon



F10-12
13A Switched Socket
With Neon+2USB



F10-13
13A Switched Socket
With Neon+USB+ Type-C



F10-14
2 Pole Switched Socket



F10-15
4 Pole Switched Socket



F10-16
20A Switch With Neon



F10-17
45A Switch With Neon



F10-18
Two Pole Socket



F10-19
MF Socket



F10-20
13A Socket



F10-21
Four Pole Socket



F10-22
5 pin MF Socket



F10-23
5 pin MF Socket+2USB



F10-24
5 pin MF Socket
+USB+2 Type-C



F10-25
5 pin MF Switched Socket
With Neon+2 USB



F10-26
5 pin MF Switched Socket
With Neon+USB+Type-C



F10-27
USB+Type-C Socket



F10-28
Double USB+Type-C
Socket



F10-29
25A Switch With Neon



F10-30
45A Switch With Neon



F10-31
Germany socket



F10-32
French socket



F10-33
Europe socket



F10-34
Satellite Socket



F10-35
TV Socket



F10-36
TEL Socket
F10-37
Computer Socket



F10-38
TV+TEL Socket



F10-39
TV+ Computer Socket



F10-40
Double Computer Socket



F10-41
Satellite+TV Socket
F10-42
Satellite+Computer Socket

F10-43
Dimmer Switch
F10-44
Speed Control Switch

F10-45
Voice Control Swith
F10-46
Touch Delay Swith

F10-47
Human Body Sensor
Switch

F10-48
Human-induced Foot Lamp

F10-49
86 Blank Plate
F10-62
146 Blank Plate

F10-50
Double 13A Switched Socket
With Neon

F10-51
Double 13A Switched Socket
With Neon+2USB

F10-52
Double 13A Switched Socket
With Neon+USB+ Type-C

F10-53
Double 13A Socket

F10-54
Double MF Switched Socket
With Neon

F10-55
Double MF Switched Socket
With Neon+2USB

F10-56
Double MF Switched Socket
With Neon+USB+ Type-C

F10-57
Cooker Unit

F10-58
Double 5 pin MF Switched Socket
With Neon

F10-59
Double 5 pin MF Switched Socket
With Neon+2USB

F10-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

F10-61
45A Switch With Neon

F10 Gray series



F10-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



F10-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



F10-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



F10-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



F10-05
Doorbell Switch



F10-06
MF Switched Socket
With Neon



F10-07
MF Switched Socket
With Neon+2USB



F10-08
MF Switched Socket
With Neon+USB+ Type-C



F10-09
15A Switched Socket
With Neon



F10-10
5 pin MF Switched Socket
With Neon



F10-11
13A Switched Socket
With Neon



F10-12
13A Switched Socket
With Neon+2USB



F10-13
13A Switched Socket
With Neon+USB+ Type-C



F10-14
2 Pole Switched Socket



F10-15
4 Pole Switched Socket



F10-16
20A Switch With Neon



F10-17
45A Switch With Neon



F10-18
Two Pole Socket



F10-19
MF Socket



F10-20
13A Socket



F10-21
Four Pole Socket



F10-22
5 pin MF Socket



F10-23
5 pin MF Socket+2USB



F10-24
5 pin MF Socket
+USB+2 Type-C



F10-25
5 pin MF Switched Socket
With Neon+2 USB



F10-26
5 pin MF Switched Socket
With Neon+USB+Type-C



F10-27
USB+Type-C Socket



F10-28
Double USB+Type-C
Socket



F10-29
25A Switch With Neon



F10-30
45A Switch With Neon



F10-31
Germany socket



F10-32
French socket



F10-33
Europe socket



F10-34
Satellite Socket



F10-35
TV Socket



F10-36
TEL Socket
F10-37
Computer Socket



F10-38
TV+TEL Socket



F10-39
TV+ Computer Socket



F10-40
Double Computer Socket



F10-41
Satellite+TV Socket
F10-42
Satellite+Computer Socket

F10-43
Dimmer Switch
F10-44
Speed Control Switch

F10-45
Voice Control Swith
F10-46
Touch Delay Swith

F10-47
Human Body Sensor
Switch

F10-48
Human-induced Foot Lamp

F10-49
86 Blank Plate
F10-62
146 Blank Plate

F10-50
Double 13A Switched Socket
With Neon

F10-51
Double 13A Switched Socket
With Neon+2USB

F10-52
Double 13A Switched Socket
With Neon+USB+ Type-C

F10-53
Double 13A Socket

F10-54
Double MF Switched Socket
With Neon

F10-55
Double MF Switched Socket
With Neon+2USB

F10-56
Double MF Switched Socket
With Neon+USB+ Type-C

F10-57
Cooker Unit

F10-58
Double 5 pin MF Switched Socket
With Neon

F10-59
Double 5 pin MF Switched Socket
With Neon+2USB

F10-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

F10-61
45A Switch With Neon

F10 Black series



F10-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



F10-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



F10-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



F10-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



F10-05
Doorbell Switch



F10-06
MF Switched Socket
With Neon



F10-07
MF Switched Socket
With Neon+2USB



F10-08
MF Switched Socket
With Neon+USB+ Type-C



F10-09
15A Switched Socket
With Neon



F10-10
5 pin MF Switched Socket
With Neon



F10-11
13A Switched Socket
With Neon



F10-12
13A Switched Socket
With Neon+2USB



F10-13
13A Switched Socket
With Neon+USB+ Type-C



F10-14
2 Pole Switched Socket



F10-15
4 Pole Switched Socket



F10-16
20A Switch With Neon



F10-17
45A Switch With Neon



F10-18
Two Pole Socket



F10-19
MF Socket



F10-20
13A Socket



F10-21
Four Pole Socket



F10-22
5 pin MF Socket



F10-23
5 pin MF Socket+2USB



F10-24
5 pin MF Socket
+USB+2 Type-C



F10-25
5 pin MF Switched Socket
With Neon+2 USB



F10-26
5 pin MF Switched Socket
With Neon+USB+Type-C



F10-27
USB+Type-C Socket



F10-28
Double USB+Type-C
Socket



F10-29
25A Switch With Neon



F10-30
45A Switch With Neon



F10-31
Germany socket



F10-32
French socket



F10-33
Europe socket



F10-34
Satellite Socket



F10-35
TV Socket



F10-36
TEL Socket
F10-37
Computer Socket



F10-38
TV+TEL Socket



F10-39
TV+ Computer Socket



F10-40
Double Computer Socket



F10-41
Satellite+TV Socket
F10-42
Satellite+Computer Socket

F10-43
Dimmer Switch
F10-44
Speed Control Switch

F10-45
Voice Control Swith
F10-46
Touch Delay Swith

F10-47
Human Body Sensor
Switch

F10-48
Human-induced Foot Lamp

F10-49
86 Blank Plate
F10-62
146 Blank Plate

F10-50
Double 13A Switched Socket
With Neon

F10-51
Double 13A Switched Socket
With Neon+2USB

F10-52
Double 13A Switched Socket
With Neon+USB+ Type-C

F10-53
Double 13A Socket

F10-54
Double MF Switched Socket
With Neon

F10-55
Double MF Switched Socket
With Neon+2USB

F10-56
Double MF Switched Socket
With Neon+USB+ Type-C

F10-57
Cooker Unit

F10-58
Double 5 pin MF Switched Socket
With Neon

F10-59
Double 5 pin MF Switched Socket
With Neon+2USB

F10-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

F10-61
45A Switch With Neon

L10
SERIES



SWITCH AND SOCKET

Good quality,enjoy the world!



Break through the limitations of switch panel design
Explore the switching limits of traditional switches

German Quality

L10 White series



L10-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



L10-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



L10-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



L10-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



L10-05
Doorbell Switch



L10-06
MF Switched Socket
With Neon



L10-07
MF Switched Socket
With Neon+2USB



L10-08
MF Switched Socket
With Neon+USB+ Type-C



L10-09
15A Switched Socket
With Neon



L10-10
5 pin MF Switched Socket
With Neon



L10-11
13A Switched Socket
With Neon



L10-12
13A Switched Socket
With Neon+2USB



L10-13
13A Switched Socket
With Neon+USB+ Type-C



L10-14
2 Pole Switched Socket



L10-15
4 Pole Switched Socket



L10-16
20A Switch With Neon



L10-17
45A Switch With Neon



L10-18
Two Pole Socket



L10-19
MF Socket



L10-20
13A Socket



L10-21
Four Pole Socket



L10-22
5 pin MF Socket



L10-23
5 pin MF Socket+2USB



L10-24
5 pin MF Socket
+USB+2 Type-C



L10-25
5 pin MF Switched Socket
With Neon+2 USB



L10-26
5 pin MF Switched Socket
With Neon+USB+Type-C



L10-27
USB+Type-C Socket



L10-28
Double USB+Type-C
Socket



L10-29
25A Switch With Neon



L10-30
45A Switch With Neon



L10-31
Germany socket



L10-32
French socket



L10-33
Europe socket



L10-34
Satellite Socket



L10-35
TV Socket



L10-36
TEL Socket
L10-37
Computer Socket



L10-38
TV+TEL Socket



L10-39
TV+ Computer Socket



L10-40
Double Computer Socket



L10-41
Satellite+TV Socket
L10-42
Satellite+Computer Socket

L10-43
Dimmer Switch
L10-44
Speed Control Switch

L10-45
Voice Control Swith
L10-46
Touch Delay Swith

L10-47
Human Body Sensor
Switch

L10-48
Human-induced Foot Lamp

L10-49
86 Blank Plate
L10-62
146 Blank Plate

L10-50
Double 13A Switched Socket
With Neon

L10-51
Double 13A Switched Socket
With Neon+2USB

L10-52
Double 13A Switched Socket
With Neon+USB+ Type-C

L10-53
Double 13A Socket

L10-54
Double MF Switched Socket
With Neon

L10-55
Double MF Switched Socket
With Neon+2USB

L10-56
Double MF Switched Socket
With Neon+USB+ Type-C

L10-57
Cooker Unit

L10-58
Double 5 pin MF Switched Socket
With Neon

L10-59
Double 5 pin MF Switched Socket
With Neon+2USB

L10-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

L10-61
45A Switch With Neon



SWITCH
AND SOCKET

Good quality,enjoy the world!

German Quality

Break through the limitations of
switch panel design
Explore the switching limits of traditional switches

SE16 White series



SE16-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



SE16-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



SE16-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



SE16-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



SE16-05
Doorbell Switch




SE16-06
MF Switched Socket
With Neon



SE16-07
MF Switched Socket
With Neon+2USB



SE16-08
MF Switched Socket
With Neon+USB+ Type-C



SE16-09
15A Switched Socket
With Neon



SE16-10
5 pin MF Switched Socket
With Neon



SE16-11
13A Switched Socket
With Neon



SE16-12
13A Switched Socket
With Neon+2USB



SE16-13
13A Switched Socket
With Neon+USB+ Type-C



SE16-14
2 Pole Switched Socket



SE16-15
4 Pole Switched Socket



SE16-16
20A Switch With Neon



SE16-17
45A Switch With Neon




SE16-18
Two Pole Socket



SE16-19
MF Socket



SE16-20
13A Socket



SE16-21
Four Pole Socket



SE16-22
5 pin MF Socket



SE16-23
5 pin MF Socket+2USB



SE16-24
5 pin MF Socket
+USB+2 Type-C



SE16-25
5 pin MF Switched Socket
With Neon+2 USB



SE16-26
5 pin MF Switched Socket
With Neon+USB+Type-C



SE16-27
USB+Type-C Socket



SE16-28
Double USB+Type-C
Socket



SE16-29
25A Switch With Neon



SE16-30
45A Switch With Neon

SE16 White series

SWITCH & SOCKET



SE16-31
Germany socket




SE16-32
French socket



SE16-33
Europe socket



SE16-34
Satellite Socket



SE16-35
TV Socket



SE16-36
TEL Socket
SE16-37
Computer Socket



SE16-38
TV+TEL Socket



SE16-39
TV+ Computer Socket



SE16-40
Double Computer Socket



SE16-41
Satellite+TV Socket
SE16-42
Satellite+Computer Socket

SE16-43
Dimmer Switch
SE16-44
Speed Control Switch

SE16-45
Voice Control Swith
SE16-46
Touch Delay Swith

SE16-47
Human Body Sensor
Switch

SE16-48
Human-induced Foot Lamp

SE16-49
86 Blank Plate
SE16-62
146 Blank Plate

SE16-50
Double 13A Switched Socket
With Neon

SE16-51
Double 13A Switched Socket
With Neon+2USB

SE16-52
Double 13A Switched Socket
With Neon+USB+ Type-C

SE16-53
Double 13A Socket

SE16-54
Double MF Switched Socket
With Neon

SE16-55
Double MF Switched Socket
With Neon+2USB

SE16-56
Double MF Switched Socket
With Neon+USB+ Type-C

SE16-57
Cooker Unit

SE16-58
Double 5 pin MF Switched Socket
With Neon

SE16-59
Double 5 pin MF Switched Socket
With Neon+2USB

SE16-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

SE16-61
45A Switch With Neon

SE16-2 White series



SE16-2-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



SE16-2-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



SE16-2-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



SE16-2-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



SE16-2-05
Doorbell Switch




SE16-2-06
MF Switched Socket
With Neon



SE16-2-07
MF Switched Socket
With Neon+2USB



SE16-2-08
MF Switched Socket
With Neon+USB+ Type-C



SE16-2-09
15A Switched Socket
With Neon



SE16-2-10
5 pin MF Switched Socket
With Neon



SE16-2-11
13A Switched Socket
With Neon




SE16-2-12
13A Switched Socket
With Neon+2USB



SE16-2-13
13A Switched Socket
With Neon+USB+ Type-C



SE16-2-14
2 Pole Switched Socket



SE16-2-15
4 Pole Switched Socket



SE16-2-16
20A Switch With Neon



SE16-2-17
45A Switch With Neon




SE16-2-18
Two Pole Socket




SE16-2-19
MF Socket



SE16-2-20
13A Socket



SE16-2-21
Four Pole Socket



SE16-2-22
5 pin MF Socket



SE16-2-23
5 pin MF Socket+2USB



SE16-2-24
5 pin MF Socket
+USB+2 Type-C



SE16-2-25
5 pin MF Switched Socket
With Neon+2 USB



SE16-2-26
5 pin MF Switched Socket
With Neon+USB+Type-C



SE16-2-27
USB+Type-C Socket



SE16-2-28
Double USB+Type-C
Socket



SE16-2-29
25A Switch With Neon



SE16-2-30
45A Switch With Neon



SE16-2-31
Germany socket




SE16-2-32
French socket



SE16-2-33
Europe socket



SE16-2-34
Satellite Socket



SE16-2-35
TV Socket



SE16-2-36
TEL Socket
SE16-2-37
Computer Socket



SE16-2-38
TV+TEL Socket



SE16-2-39
TV+ Computer Socket



SE16-2-40
Double Computer Socket



SE16-2-41
Satellite+TV Socket
SE16-2-42
Satellite+Computer Socket

SE16-2-43
Dimmer Switch
SE16-2-44
Speed Control Switch

SE16-2-45
Voice Control Swith
SE16-2-46
Touch Delay Swith

SE16-2-47
Human Body Sensor
Switch

SE16-2-48
Human-induced Foot Lamp

SE16-2-49
86 Blank Plate
SE16-2-62
146 Blank Plate

SE16-2-50
Double 13A Switched Socket
With Neon

SE16-2-51
Double 13A Switched Socket
With Neon+2USB

SE16-2-52
Double 13A Switched Socket
With Neon+USB+ Type-C

SE16-2-53
Double 13A Socket

SE16-2-54
Double MF Switched Socket
With Neon

SE16-2-55
Double MF Switched Socket
With Neon+2USB

SE16-2-56
Double MF Switched Socket
With Neon+USB+ Type-C

SE16-2-57
Cooker Unit

SE16-2-58
Double 5 pin MF Switched Socket
With Neon

SE16-2-59
Double 5 pin MF Switched Socket
With Neon+2USB

SE16-2-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

SE16-2-61
45A Switch With Neon

SE18 White series



SE18-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



SE18-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



SE18-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



SE18-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



SE18-05
Doorbell Switch



SE18-06
MF Switched Socket
With Neon



SE18-07
MF Switched Socket
With Neon+2USB



SE18-08
MF Switched Socket
With Neon+USB+ Type-C



SE18-09
15A Switched Socket
With Neon



SE18-10
5 pin MF Switched Socket
With Neon



SE18-11
13A Switched Socket
With Neon




SE18-12
13A Switched Socket
With Neon+2USB



SE18-13
13A Switched Socket
With Neon+USB+ Type-C



SE18-14
2 Pole Switched Socket



SE18-15
4 Pole Switched Socket



SE18-16
20A Switch With Neon



SE18-17
45A Switch With Neon




SE18-18
Two Pole Socket



SE18-19
MF Socket



SE18-20
13A Socket



SE18-21
Four Pole Socket



SE18-22
5 pin MF Socket



SE18-23
5 pin MF Socket+2USB



SE18-24
5 pin MF Socket
+USB+2 Type-C



SE18-25
5 pin MF Switched Socket
With Neon+2 USB



SE18-26
5 pin MF Switched Socket
With Neon+USB+Type-C



SE18-27
USB+Type-C Socket



SE18-28
Double USB+Type-C
Socket



SE18-29
25A Switch With Neon



SE18-30
45A Switch With Neon



SE18-31
Germany socket



SE18-32
French socket



SE18-33
Europe socket



SE18-34
Satellite Socket



SE18-35
TV Socket



SE18-36
TEL Socket
SE18-37
Computer Socket



SE18-38
TV+TEL Socket



SE18-39
TV+ Computer Socket



SE18-40
Double Computer Socket



SE18-41
Satellite+TV Socket
SE18-42
Satellite+Computer Socket

SE18-43
Dimmer Switch
SE18-44
Speed Control Switch

SE18-45
Voice Control Swith
SE18-46
Touch Delay Swith

SE18-47
Human Body Sensor
Switch

SE18-48
Human-induced Foot Lamp

SE18-49
86 Blank Plate
SE18-62
146 Blank Plate

SE18-50
Double 13A Switched Socket
With Neon

SE18-51
Double 13A Switched Socket
With Neon+2USB

SE18-52
Double 13A Switched Socket
With Neon+USB+ Type-C

SE18-53
Double 13A Socket

SE18-54
Double MF Switched Socket
With Neon

SE18-55
Double MF Switched Socket
With Neon+2USB

SE18-56
Double MF Switched Socket
With Neon+USB+ Type-C

SE18-57
Cooker Unit

SE18-58
Double 5 pin MF Switched Socket
With Neon

SE18-59
Double 5 pin MF Switched Socket
With Neon+2USB

SE18-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C


SE18-61
45A Switch With Neon



H1 series

When the eye is at rest, it can focus on the essential features of things. as if the series focused on
Austere pragmatism, combined with specific colors in harmony with modern architectural design,
its tough and simple design.
The clear and independent personality is particularly captivating,
and the matte black and matte white are visually and tactilely shocking, making people feeldeep impression.





H1 White series



H1-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



H1-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



H1-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



H1-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch




H1-05
Doorbell Switch




H1-06
MF Big Switched Socket
With Neon




H1-07
13A Big Switched Socket
With Neon



H1-08
5 pin MF Big Switched
Socket With Neon




H1-09
MF Switched Socket
With Neon




H1-10
MF Switched Socket
With Neon+2USB




H1-11
MF Switched Socket
With Neon+USB+ Type-C




H1-12
15A Switched Socket
With Neon



H1-13
5 pin MF Switched Socket
With Neon



H1-14
13A Switched Socket
With Neon




H1-15
13A Switched Socket
With Neon+2USB



H1-16
13A Switched Socket
With Neon+USB+ Type-C



H1-17
2 Pole Switched Socket



H1-18
4 Pole Switched Socket



H1-19
20A Switch With Neon




H1-20
45A Switch With Neon



H1-21
Two Pole Socket




H1-22
13A Socket




H1-23
Four Pole Socket




H1-24
5 pin MF Socket



H1-25
5 pin MF Socket
+USB+2 Type-C



H1-26
5 pin MF Switched Socket
With Neon+2 USB



H1-27
5 pin MF Switched Socket
With Neon+USB+Type-C



H1-28
USB+Type-C Socket



H1-29
Double USB+Type-C
Socket



H1-30
25A Switch With Neon



H1-31
45A Switch With Neon



H1-32
Germany socket



H1-33
French socket



H1-34
Europe socket



H1-35
Satellite Socket



H1-36
TV Socket



H1-37
TEL Socket
H1-38
Computer Socket



H1-39
TV+TEL Socket



H1-40
TV+ Computer Socket
H1-41
Double Computer Socket



H1-42
Satellite+TV Socket
H1-43
Satellite+Computer Socket

H1-44
Dimmer Switch
H1-45
Speed Control Switch

H1-46
Voice Control Swith
H1-47
Touch Delay Swith

H1-48
Human Body Sensor
Switch

H1-49
Human-induced Foot Lamp

H1-50
86 Blank Plate
H1-63
146 Blank Plate

H1-51
Double 13A Switched Socket
With Neon

H1-52
Double 13A Switched Socket
With Neon+2USB

H1-53
Double 13A Switched Socket
With Neon+USB+ Type-C

H1-54
Double 13A Socket

H1-55
Double MF Switched Socket
With Neon

H1-56
Double MF Switched Socket
With Neon+2USB

H1-57
Double MF Switched Socket
With Neon+USB+ Type-C

H1-58
Cooker Unit

H1-59
Double 5 pin MF Switched Socket
With Neon

H1-60
Double 5 pin MF Switched Socket
With Neon+2USB

H1-61
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

H1-62
45A Switch With Neon



When the eye is at rest, it can focus on the essential features of things. as if the series focused on
Austere pragmatism, combined with specific colors in harmony with modern architectural design,
its tough and simple design.
The clear and independent personality is particularly captivating,
and the matte black and matte white are visually and tactilely shocking, making people feeldeep impression.



H2 series

Wire Drawing

H2 White series



H2-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



H2-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



H2-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



H2-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



H2-05
Doorbell Switch



H2-06
MF Big Switched Socket
With Neon



H2-07
13A Big Switched Socket
With Neon



H2-08
5 pin MF Big Switched
Socket With Neon



H2-09
MF Switched Socket
With Neon



H2-10
MF Switched Socket
With Neon+2USB



H2-11
MF Switched Socket
With Neon+USB+ Type-C



H2-12
15A Switched Socket
With Neon



H2-13
5 pin MF Switched Socket
With Neon



H2-14
13A Switched Socket
With Neon



H2-15
13A Switched Socket
With Neon+2USB



H2-16
13A Switched Socket
With Neon+USB+ Type-C



H2-17
2 Pole Switched Socket



H2-18
4 Pole Switched Socket



H2-19
20A Switch With Neon



H2-20
45A Switch With Neon



H2-21
Two Pole Socket



H2-22
13A Socket



H2-23
Four Pole Socket



H2-24
5 pin MF Socket



H2-25
5 pin MF Socket
+USB+2 Type-C



H2-26
5 pin MF Switched Socket
With Neon+2 USB



H2-27
5 pin MF Switched Socket
With Neon+USB+Type-C



H2-28
USB+Type-C Socket



H2-29
Double USB+Type-C
Socket



H2-30
25A Switch With Neon



H2-31
45A Switch With Neon



H2-32
Germany socket



H2-33
French socket



H2-34
Europe socket



H2-35
Satellite Socket



H2-36
TV Socket



H2-37
TEL Socket
H2-38
Computer Socket



H2-39
TV+TEL Socket



H2-40
TV+ Computer Socket
H2-41
Double Computer Socket



H2-42
Satellite+TV Socket
H2-43
Satellite+Computer Socket

H2-44
Dimmer Switch
H2-45
Speed Control Switch

H2-46
Voice Control Swith
H2-47
Touch Delay Swith

H2-48
Human Body Sensor
Switch

H2-49
Human-induced Foot Lamp

H2-50
86 Blank Plate
H2-63
146 Blank Plate

H2-51
Double 13A Switched Socket
With Neon

H2-52
Double 13A Switched Socket
With Neon+2USB

H2-53
Double 13A Switched Socket
With Neon+USB+ Type-C

H2-54
Double 13A Socket

H2-55
Double MF Switched Socket
With Neon

H2-56
Double MF Switched Socket
With Neon+2USB

H2-57
Double MF Switched Socket
With Neon+USB+ Type-C

H2-58
Cooker Unit


H2-59
Double 5 pin MF Switched Socket
With Neon

H2-60
Double 5 pin MF Switched Socket
With Neon+2USB

H2-61
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

H2-62
45A Switch With Neon

H3 series



When the eye is at rest, it can focus on the essential features of things. as if the series focused on
Austere pragmatism, combined with specific colors in harmony with modern architectural design,
its tough and simple design.
The clear and independent personality is particularly captivating,
and the matte black and matte white are visually and tactilely shocking, making people feeldeep impression.

H3 Gray series



H3-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



H3-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



H3-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



H3-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



H3-05
Doorbell Switch



H3-06
MF Big Switched Socket
With Neon



H3-07
13A Big Switched Socket
With Neon



H3-08
5 pin MF Big Switched
Socket With Neon



H3-09
MF Switched Socket
With Neon



H3-10
MF Switched Socket
With Neon+2USB



H3-11
MF Switched Socket
With Neon+USB+ Type-C



H3-12
15A Switched Socket
With Neon



H3-13
5 pin MF Switched Socket
With Neon



H3-14
13A Switched Socket
With Neon



H3-15
13A Switched Socket
With Neon+2USB



H3-16
13A Switched Socket
With Neon+USB+ Type-C



H3-17
2 Pole Switched Socket



H3-18
4 Pole Switched Socket



H3-19
20A Switch With Neon



H3-20
45A Switch With Neon



H3-21
Two Pole Socket



H3-22
13A Socket



H3-23
Four Pole Socket



H3-24
5 pin MF Socket



H3-25
5 pin MF Socket
+USB+2 Type-C



H3-26
5 pin MF Switched Socket
With Neon+2 USB



H3-27
5 pin MF Switched Socket
With Neon+USB+Type-C



H3-28
USB+Type-C Socket



H3-29
Double USB+Type-C
Socket



H3-30
25A Switch With Neon



H3-31
45A Switch With Neon



H3-32
Germany socket



H3-33
French socket



H3-34
Europe socket



H3-35
Satellite Socket



H3-36
TV Socket



H3-37
TEL Socket
H3-38
Computer Socket



H3-39
TV+TEL Socket



H3-40
TV+ Computer Socket
H3-41
Double Computer Socket



H3-42
Satellite+TV Socket
H3-43
Satellite+Computer Socket

H3-44
Dimmer Switch
H3-45
Speed Control Switch

H3-46
Voice Control Swith
H3-47
Touch Delay Swith

H3-48
Human Body Sensor
Switch

H3-49
Human-induced Foot Lamp

H3-50
86 Blank Plate
H3-63
146 Blank Plate

H3-51
Double 13A Switched Socket
With Neon

H3-52
Double 13A Switched Socket
With Neon+2USB

H3-53
Double 13A Switched Socket
With Neon+USB+ Type-C

H3-54
Double 13A Socket

H3-55
Double MF Switched Socket
With Neon

H3-56
Double MF Switched Socket
With Neon+2USB

H3-57
Double MF Switched Socket
With Neon+USB+ Type-C

H3-58
Cooker Unit

H3-59
Double 5 pin MF Switched Socket
With Neon

H3-60
Double 5 pin MF Switched Socket
With Neon+2USB

H3-61
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

H3-62
45A Switch With Neon

Ultra-Thin PMMA



T6 series

White Gold Black



Provide the global home with great idea and create a beautiful home,
its electricalaccessories not only excellent in function.
but also add unlimited fun and personalized features for your living space,
we brought together singularity withinspiration, will create a unique household environment for you.

T6 | White series

Ultra-thin PMMA



T6-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T6-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T6-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T6-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T6-05
Doorbell Switch



T6-06
MF Switched Socket
With Neon



T6-07
MF Switched Socket
With Neon+2USB



T6-08
MF Switched Socket
With Neon+USB+ Type-C



T6-09
15A Switched Socket
With Neon



T6-10
5 pin MF Switched Socket
With Neon



T6-11
13A Switched Socket
With Neon



T6-12
13A Switched Socket
With Neon+2USB



T6-13
13A Switched Socket
With Neon+USB+ Type-C



T6-14
2 Pole Switched Socket



T6-15
4 Pole Switched Socket



T6-16
20A Switch With Neon



T6-17
45A Switch With Neon



T6-18
Two Pole Socket



T6-19
MF Socket



T6-20
13A Socket



T6-21
Four Pole Socket



T6-22
5 pin MF Socket



T6-23
5 pin MF Socket+2USB



T6-24
5 pin MF Socket
+USB+2 Type-C



T6-25
5 pin MF Switched Socket
With Neon+2 USB



T6-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T6-27
USB+Type-C Socket



T6-28
Double USB+Type-C
Socket



T6-29
25A Switch With Neon



T6-30
45A Switch With Neon

T6 | White series

SWITCH & SOCKET



T6-31
Germany socket



T6-32
French socket



T6-33
Europe socket



T6-34
Satellite Socket



T6-35
TV Socket



T6-36
TEL Socket
T6-37
Computer Socket



T6-38
TV+TEL Socket



T6-39
TV+ Computer Socket



T6-40
Double Computer Socket



T6-41
Satellite+TV Socket
T6-42
Satellite+Computer Socket

T6-43
Dimmer Switch
T6-44
Speed Control Switch

T6-45
Voice Control Swith
T6-46
Touch Delay Swith

T6-47
Human Body Sensor
Switch

T6-48
Human-induced Foot Lamp

T6-49
86 Blank Plate
T6-62
146 Blank Plate

T6-50
Double 13A Switched Socket
With Neon

T6-51
Double 13A Switched Socket
With Neon+2USB

T6-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T6-53
Double 13A Socket

T6-54
Double MF Switched Socket
With Neon

T6-55
Double MF Switched Socket
With Neon+2USB

T6-56
Double MF Switched Socket
With Neon+USB+ Type-C

T6-57
Cooker Unit

T6-58
Double 5 pin MF Switched Socket
With Neon

T6-59
Double 5 pin MF Switched Socket
With Neon+2USB

T6-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T6-61
45A Switch With Neon

T6 | Gold series

Ultra-thin PMMA



T6-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T6-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T6-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T6-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T6-05
Doorbell Switch



T6-06
MF Switched Socket
With Neon



T6-07
MF Switched Socket
With Neon+2USB



T6-08
MF Switched Socket
With Neon+USB+ Type-C



T6-09
15A Switched Socket
With Neon



T6-10
5 pin MF Switched Socket
With Neon



T6-11
13A Switched Socket
With Neon



T6-12
13A Switched Socket
With Neon+2USB



T6-13
13A Switched Socket
With Neon+USB+ Type-C



T6-14
2 Pole Switched Socket



T6-15
4 Pole Switched Socket



T6-16
20A Switch With Neon



T6-17
45A Switch With Neon



T6-18
Two Pole Socket



T6-19
MF Socket



T6-20
13A Socket



T6-21
Four Pole Socket



T6-22
5 pin MF Socket



T6-23
5 pin MF Socket+2USB



T6-24
5 pin MF Socket
+USB+2 Type-C



T6-25
5 pin MF Switched Socket
With Neon+2 USB



T6-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T6-27
USB+Type-C Socket



T6-28
Double USB+Type-C
Socket



T6-29
25A Switch With Neon



T6-30
45A Switch With Neon

T6 | Gold series

SWITCH & SOCKET



T6-31
Germany socket



T6-32
French socket



T6-33
Europe socket



T6-34
Satellite Socket



T6-35
TV Socket



T6-36
TEL Socket
T6-37
Computer Socket



T6-38
TV+TEL Socket



T6-39
TV+ Computer Socket



T6-40
Double Computer Socket



T6-41
Satellite+TV Socket
T6-42
Satellite+Computer Socket

T6-43
Dimmer Switch
T6-44
Speed Control Switch

T6-45
Voice Control Swith
T6-46
Touch Delay Swith

T6-47
Human Body Sensor
Switch

T6-48
Human-induced Foot Lamp

T6-49
86 Blank Plate
T6-62
146 Blank Plate

T6-50
Double 13A Switched Socket
With Neon

T6-51
Double 13A Switched Socket
With Neon+2USB

T6-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T6-53
Double 13A Socket

T6-54
Double MF Switched Socket
With Neon

T6-55
Double MF Switched Socket
With Neon+2USB

T6-56
Double MF Switched Socket
With Neon+USB+ Type-C

T6-57
Cooker Unit

T6-58
Double 5 pin MF Switched Socket
With Neon

T6-59
Double 5 pin MF Switched Socket
With Neon+2USB

T6-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T6-61
45A Switch With Neon

T6 Black series

Ultra-thin PMMA



T6-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T6-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T6-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T6-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T6-05
Doorbell Switch



T6-06
MF Switched Socket
With Neon



T6-07
MF Switched Socket
With Neon+2USB



T6-08
MF Switched Socket
With Neon+USB+ Type-C



T6-09
15A Switched Socket
With Neon



T6-10
5 pin MF Switched Socket
With Neon



T6-11
13A Switched Socket
With Neon



T6-12
13A Switched Socket
With Neon+2USB



T6-13
13A Switched Socket
With Neon+USB+ Type-C



T6-14
2 Pole Switched Socket



T6-15
4 Pole Switched Socket



T6-16
20A Switch With Neon



T6-17
45A Switch With Neon



T6-18
Two Pole Socket



T6-19
MF Socket



T6-20
13A Socket



T6-21
Four Pole Socket



T6-22
5 pin MF Socket



T6-23
5 pin MF Socket+2USB



T6-24
5 pin MF Socket
+USB+2 Type-C



T6-25
5 pin MF Switched Socket
With Neon+2 USB



T6-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T6-27
USB+Type-C Socket



T6-28
Double USB+Type-C
Socket



T6-29
25A Switch With Neon



T6-30
45A Switch With Neon



T6-31
Germany socket



T6-32
French socket



T6-33
Europe socket



T6-34
Satellite Socket



T6-35
TV Socket



T6-36
TEL Socket
T6-37
Computer Socket



T6-38
TV+TEL Socket



T6-39
TV+ Computer Socket



T6-40
Double Computer Socket



T6-41
Satellite+TV Socket
T6-42
Satellite+Computer Socket

T6-43
Dimmer Switch
T6-44
Speed Control Switch

T6-45
Voice Control Swith
T6-46
Touch Delay Swith

T6-47
Human Body Sensor
Switch

T6-48
Human-induced Foot Lamp

T6-49
86 Blank Plate
T6-62
146 Blank Plate

T6-50
Double 13A Switched Socket
With Neon

T6-51
Double 13A Switched Socket
With Neon+2USB

T6-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T6-53
Double 13A Socket

T6-54
Double MF Switched Socket
With Neon

T6-55
Double MF Switched Socket
With Neon+2USB

T6-56
Double MF Switched Socket
With Neon+USB+ Type-C

T6-57
Cooker Unit

T6-58
Double 5 pin MF Switched Socket
With Neon

T6-59
Double 5 pin MF Switched Socket
With Neon+2USB

T6-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T6-61
45A Switch With Neon

SWITCH
SOCKET



T8 series

White Gold Grey Black

Ultra-thin Skin-sensitive PMMA

T8 White series

Ultra-thin Skin-sensitive PMMA

T8-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch

T8-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T8-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T8-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T8-05
Doorbell Switch



T8-06
MF Switched Socket
With Neon



T8-07
MF Switched Socket
With Neon+2USB



T8-08
MF Switched Socket
With Neon+USB+ Type-C



T8-09
15A Switched Socket
With Neon



T8-10
5 pin MF Switched Socket
With Neon



T8-11
13A Switched Socket
With Neon



T8-12
13A Switched Socket
With Neon+2USB



T8-13
13A Switched Socket
With Neon+USB+ Type-C



T8-14
2 Pole Switched Socket



T8-15
4 Pole Switched Socket



T8-16
20A Switch With Neon



T8-17
45A Switch With Neon



T8-18
Two Pole Socket



T8-19
MF Socket



T8-20
13A Socket



T8-21
Four Pole Socket



T8-22
5 pin MF Socket



T8-23
5 pin MF Socket+2USB



T8-24
5 pin MF Socket
+USB+2 Type-C



T8-25
5 pin MF Switched Socket
With Neon+2 USB



T8-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T8-27
USB+Type-C Socket



T8-28
Double USB+Type-C
Socket



T8-29
25A Switch With Neon



T8-30
45A Switch With Neon

T8 White series

SWITCH & SOCKET



T8-31
Germany socket



T8-32
French socket



T8-33
Europe socket



T8-34
Satellite Socket



T8-35
TV Socket



T8-36
TEL Socket
T8-37
Computer Socket



T8-38
TV+TEL Socket



T8-39
TV+ Computer Socket



T8-40
Double Computer Socket



T8-41
Satellite+TV Socket
T8-42
Satellite+Computer Socket

T8-43
Dimmer Switch
T8-44
Speed Control Switch

T8-45
Voice Control Swith
T8-46
Touch Delay Swith

T8-47
Human Body Sensor
Switch

T8-48
Human-induced Foot Lamp

T8-49
86 Blank Plate
T8-62
146 Blank Plate

T8-50
Double 13A Switched Socket
With Neon

T8-51
Double 13A Switched Socket
With Neon+2USB

T8-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T8-53
Double 13A Socket

T8-54
Double MF Switched Socket
With Neon

T8-55
Double MF Switched Socket
With Neon+2USB

T8-56
Double MF Switched Socket
With Neon+USB+ Type-C

T8-57
Cooker Unit

T8-58
Double 5 pin MF Switched Socket
With Neon

T8-59
Double 5 pin MF Switched Socket
With Neon+2USB

T8-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T8-61
45A Switch With Neon

T8 Gold series

Ultra-thin Skin-sensitive PMMA

T8-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T8-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T8-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T8-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T8-05
Doorbell Switch



T8-06
MF Switched Socket
With Neon



T8-07
MF Switched Socket
With Neon+2USB



T8-08
MF Switched Socket
With Neon+USB+ Type-C



T8-09
15A Switched Socket
With Neon



T8-10
5 pin MF Switched Socket
With Neon



T8-11
13A Switched Socket
With Neon



T8-12
13A Switched Socket
With Neon+2USB



T8-13
13A Switched Socket
With Neon+USB+ Type-C



T8-14
2 Pole Switched Socket



T8-15
4 Pole Switched Socket



T8-16
20A Switch With Neon



T8-17
45A Switch With Neon



T8-18
Two Pole Socket



T8-19
MF Socket



T8-20
13A Socket



T8-21
Four Pole Socket



T8-22
5 pin MF Socket



T8-23
5 pin MF Socket+2USB



T8-24
5 pin MF Socket
+USB+2 Type-C



T8-25
5 pin MF Switched Socket
With Neon+2 USB



T8-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T8-27
USB+Type-C Socket



T8-28
Double USB+Type-C
Socket



T8-29
25A Switch With Neon



T8-30
45A Switch With Neon



T8-31
Germany socket



T8-32
French socket



T8-33
Europe socket



T8-34
Satellite Socket



T8-35
TV Socket



T8-36
TEL Socket
T8-37
Computer Socket



T8-38
TV+TEL Socket



T8-39
TV+ Computer Socket



T8-40
Double Computer Socket



T8-41
Satellite+TV Socket
T8-42
Satellite+Computer Socket

T8-43
Dimmer Switch
T8-44
Speed Control Switch

T8-45
Voice Control Swith
T8-46
Touch Delay Swith

T8-47
Human Body Sensor
Switch

T8-48
Human-induced Foot Lamp

T8-49
86 Blank Plate
T8-62
146 Blank Plate

T8-50
Double 13A Switched Socket
With Neon

T8-51
Double 13A Switched Socket
With Neon+2USB

T8-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T8-53
Double 13A Socket

T8-54
Double MF Switched Socket
With Neon

T8-55
Double MF Switched Socket
With Neon+2USB

T8-56
Double MF Switched Socket
With Neon+USB+ Type-C

T8-57
Cooker Unit

T8-58
Double 5 pin MF Switched Socket
With Neon

T8-59
Double 5 pin MF Switched Socket
With Neon+2USB

T8-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T8-61
45A Switch With Neon

T8 Gray series — Ultra-thin Skin-sensitive PMMA



T8-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T8-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T8-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T8-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T8-05
Doorbell Switch



T8-06
MF Switched Socket
With Neon



T8-07
MF Switched Socket
With Neon+2USB



T8-08
MF Switched Socket
With Neon+USB+ Type-C



T8-09
15A Switched Socket
With Neon



T8-10
5 pin MF Switched Socket
With Neon



T8-11
13A Switched Socket
With Neon



T8-12
13A Switched Socket
With Neon+2USB



T8-13
13A Switched Socket
With Neon+USB+ Type-C



T8-14
2 Pole Switched Socket



T8-15
4 Pole Switched Socket



T8-16
20A Switch With Neon



T8-17
45A Switch With Neon



T8-18
Two Pole Socket



T8-19
MF Socket



T8-20
13A Socket



T8-21
Four Pole Socket



T8-22
5 pin MF Socket



T8-23
5 pin MF Socket+2USB



T8-24
5 pin MF Socket
+USB+2 Type-C



T8-25
5 pin MF Switched Socket
With Neon+2 USB



T8-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T8-27
USB+Type-C Socket



T8-28
Double USB+Type-C
Socket



T8-29
25A Switch With Neon



T8-30
45A Switch With Neon

T8 Gray series — SWITCH & SOCKET



T8-31
Germany socket



T8-32
French socket



T8-33
Europe socket



T8-34
Satellite Socket



T8-35
TV Socket



T8-36
TEL Socket
T8-37
Computer Socket



T8-38
TV+TEL Socket



T8-39
TV+ Computer Socket



T8-40
Double Computer Socket



T8-41
Satellite+TV Socket
T8-42
Satellite+Computer Socket

T8-43
Dimmer Switch
T8-44
Speed Control Switch

T8-45
Voice Control Swith
T8-46
Touch Delay Swith

T8-47
Human Body Sensor
Switch

T8-48
Human-induced Foot Lamp

T8-49
86 Blank Plate
T8-62
146 Blank Plate

T8-50
Double 13A Switched Socket
With Neon

T8-51
Double 13A Switched Socket
With Neon+2USB

T8-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T8-53
Double 13A Socket

T8-54
Double MF Switched Socket
With Neon

T8-55
Double MF Switched Socket
With Neon+2USB

T8-56
Double MF Switched Socket
With Neon+USB+ Type-C

T8-57
Cooker Unit

T8-58
Double 5 pin MF Switched Socket
With Neon

T8-59
Double 5 pin MF Switched Socket
With Neon+2USB

T8-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T8-61
45A Switch With Neon

T8 Black series

Ultra-thin Skin-sensitive PMMA



T8-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T8-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T8-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T8-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T8-05
Doorbell Switch



T8-06
MF Switched Socket
With Neon



T8-07
MF Switched Socket
With Neon+2USB



T8-08
MF Switched Socket
With Neon+USB+ Type-C



T8-09
15A Switched Socket
With Neon



T8-10
5 pin MF Switched Socket
With Neon



T8-11
13A Switched Socket
With Neon



T8-12
13A Switched Socket
With Neon+2USB



T8-13
13A Switched Socket
With Neon+USB+ Type-C



T8-14
2 Pole Switched Socket



T8-15
4 Pole Switched Socket



T8-16
20A Switch With Neon



T8-17
45A Switch With Neon



T8-18
Two Pole Socket



T8-19
MF Socket



T8-20
13A Socket



T8-21
Four Pole Socket



T8-22
5 pin MF Socket



T8-23
5 pin MF Socket+2USB



T8-24
5 pin MF Socket
+USB+2 Type-C



T8-25
5 pin MF Switched Socket
With Neon+2 USB



T8-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T8-27
USB+Type-C Socket



T8-28
Double USB+Type-C
Socket



T8-29
25A Switch With Neon



T8-30
45A Switch With Neon

T8 Black series

SWITCH & SOCKET



T8-31
Germany socket



T8-32
French socket



T8-33
Europe socket



T8-34
Satellite Socket



T8-35
TV Socket



T8-36
TEL Socket
T8-37
Computer Socket



T8-38
TV+TEL Socket



T8-39
TV+ Computer Socket



T8-40
Double Computer Socket



T8-41
Satellite+TV Socket
T8-42
Satellite+Computer Socket

T8-43
Dimmer Switch
T8-44
Speed Control Switch

T8-45
Voice Control Swith
T8-46
Touch Delay Swith

T8-47
Human Body Sensor
Switch

T8-48
Human-induced Foot Lamp

T8-49
86 Blank Plate
T8-62
146 Blank Plate

T8-50
Double 13A Switched Socket
With Neon

T8-51
Double 13A Switched Socket
With Neon+2USB

T8-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T8-53
Double 13A Socket

T8-54
Double MF Switched Socket
With Neon

T8-55
Double MF Switched Socket
With Neon+2USB

T8-56
Double MF Switched Socket
With Neon+USB+ Type-C

T8-57
Cooker Unit

T8-58
Double 5 pin MF Switched Socket
With Neon

T8-59
Double 5 pin MF Switched Socket
With Neon+2USB

T8-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T8-61
45A Switch With Neon

SWITCH
SOCKET





T9 series Ultra-thin Texture

T9 | Gray series

Ultra-thin Texture



T9-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T9-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T9-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T9-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T9-05
Doorbell Switch



T9-06
MF Switched Socket
With Neon



T9-07
MF Switched Socket
With Neon+2USB



T9-08
MF Switched Socket
With Neon+USB+ Type-C



T9-09
15A Switched Socket
With Neon



T9-10
5 pin MF Switched Socket
With Neon



T9-11
13A Switched Socket
With Neon



T9-12
13A Switched Socket
With Neon+2USB



T9-13
13A Switched Socket
With Neon+USB+ Type-C



T9-14
2 Pole Switched Socket



T9-15
4 Pole Switched Socket



T9-16
20A Switch With Neon



T9-17
45A Switch With Neon



T9-18
Two Pole Socket



T9-19
MF Socket



T9-20
13A Socket



T9-21
Four Pole Socket



T9-22
5 pin MF Socket



T9-23
5 pin MF Socket+2USB



T9-24
5 pin MF Socket
+USB+2 Type-C



T9-25
5 pin MF Switched Socket
With Neon+2 USB



T9-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T9-27
USB+Type-C Socket



T9-28
Double USB+Type-C
Socket



T9-29
25A Switch With Neon



T9-30
45A Switch With Neon



T9-31
Germany socket



T9-32
French socket



T9-33
Europe socket




T9-34
Satellite Socket



T9-35
TV Socket



T9-36
TEL Socket
T9-37
Computer Socket



T9-38
TV+TEL Socket



T9-39
TV+ Computer Socket



T9-40
Double Computer Socket



T9-41
Satellite+TV Socket
T9-42
Satellite+Computer Socket

T9-43
Dimmer Switch
T9-44
Speed Control Switch

T9-45
Voice Control Swith
T9-46
Touch Delay Swith

T9-47
Human Body Sensor
Switch

T9-48
Human-induced Foot Lamp

T9-49
86 Blank Plate
T9-62
146 Blank Plate

T9-50
Double 13A Switched Socket
With Neon

T9-51
Double 13A Switched Socket
With Neon+2USB

T9-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T9-53
Double 13A Socket

T9-54
Double MF Switched Socket
With Neon

T9-55
Double MF Switched Socket
With Neon+2USB

T9-56
Double MF Switched Socket
With Neon+USB+ Type-C

T9-57
Cooker Unit

T9-58
Double 5 pin MF Switched Socket
With Neon

T9-59
Double 5 pin MF Switched Socket
With Neon+2USB

T9-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T9-61
45A Switch With Neon

T9 | Black series

Ultra-thin Texture



T9-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T9-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T9-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T9-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T9-05
Doorbell Switch



T9-06
MF Switched Socket
With Neon



T9-07
MF Switched Socket
With Neon+2USB



T9-08
MF Switched Socket
With Neon+USB+ Type-C



T9-09
15A Switched Socket
With Neon



T9-10
5 pin MF Switched Socket
With Neon



T9-11
13A Switched Socket
With Neon



T9-12
13A Switched Socket
With Neon+2USB



T9-13
13A Switched Socket
With Neon+USB+ Type-C



T9-14
2 Pole Switched Socket



T9-15
4 Pole Switched Socket



T9-16
20A Switch With Neon



T9-17
45A Switch With Neon



T9-18
Two Pole Socket



T9-19
MF Socket



T9-20
13A Socket



T9-21
Four Pole Socket



T9-22
5 pin MF Socket



T9-23
5 pin MF Socket+2USB



T9-24
5 pin MF Socket
+USB+2 Type-C



T9-25
5 pin MF Switched Socket
With Neon+2 USB



T9-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T9-27
USB+Type-C Socket



T9-28
Double USB+Type-C
Socket



T9-29
25A Switch With Neon



T9-30
45A Switch With Neon

T9 | Black series

SWITCH & SOCKET



T9-31
Germany socket



T9-32
French socket



T9-33
Europe socket



T9-34
Satellite Socket



T9-35
TV Socket



T9-36
TEL Socket
T9-37
Computer Socket



T9-38
TV+TEL Socket



T9-39
TV+ Computer Socket



T9-40
Double Computer Socket



T9-41
Satellite+TV Socket
T9-42
Satellite+Computer Socket

T9-43
Dimmer Switch
T9-44
Speed Control Switch

T9-45
Voice Control Swith
T9-46
Touch Delay Swith

T9-47
Human Body Sensor
Switch

T9-48
Human-induced Foot Lamp

T9-49
86 Blank Plate
T9-62
146 Blank Plate

T9-50
Double 13A Switched Socket
With Neon

T9-51
Double 13A Switched Socket
With Neon+2USB

T9-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T9-53
Double 13A Socket

T9-54
Double MF Switched Socket
With Neon

T9-55
Double MF Switched Socket
With Neon+2USB

T9-56
Double MF Switched Socket
With Neon+USB+ Type-C

T9-57
Cooker Unit

T9-58
Double 5 pin MF Switched Socket
With Neon

T9-59
Double 5 pin MF Switched Socket
With Neon+2USB

T9-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T9-61
45A Switch With Neon

T9 | Coffee series

Ultra-thin Texture



T9-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T9-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T9-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T9-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T9-05
Doorbell Switch



T9-06
MF Switched Socket
With Neon



T9-07
MF Switched Socket
With Neon+2USB



T9-08
MF Switched Socket
With Neon+USB+ Type-C



T9-09
15A Switched Socket
With Neon



T9-10
5 pin MF Switched Socket
With Neon



T9-11
13A Switched Socket
With Neon



T9-12
13A Switched Socket
With Neon+2USB



T9-13
13A Switched Socket
With Neon+USB+ Type-C



T9-14
2 Pole Switched Socket



T9-15
4 Pole Switched Socket



T9-16
20A Switch With Neon



T9-17
45A Switch With Neon



T9-18
Two Pole Socket



T9-19
MF Socket



T9-20
13A Socket



T9-21
Four Pole Socket



T9-22
5 pin MF Socket



T9-23
5 pin MF Socket+2USB



T9-24
5 pin MF Socket
+USB+2 Type-C



T9-25
5 pin MF Switched Socket
With Neon+2 USB



T9-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T9-27
USB+Type-C Socket



T9-28
Double USB+Type-C
Socket



T9-29
25A Switch With Neon



T9-30
45A Switch With Neon

T9 | Coffee series

SWITCH & SOCKET



T9-31
Germany socket



T9-32
French socket



T9-33
Europe socket



T9-34
Satellite Socket



T9-35
TV Socket



T9-36
TEL Socket
T9-37
Computer Socket



T9-38
TV+TEL Socket



T9-39
TV+ Computer Socket



T9-40
Double Computer Socket



T9-41
Satellite+TV Socket
T9-42
Satellite+Computer Socket

T9-43
Dimmer Switch
T9-44
Speed Control Switch

T9-45
Voice Control Swith
T9-46
Touch Delay Swith

T9-47
Human Body Sensor
Switch

T9-48
Human-induced Foot Lamp

T9-49
86 Blank Plate
T9-62
146 Blank Plate

T9-50
Double 13A Switched Socket
With Neon

T9-51
Double 13A Switched Socket
With Neon+2USB

T9-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T9-53
Double 13A Socket

T9-54
Double MF Switched Socket
With Neon

T9-55
Double MF Switched Socket
With Neon+2USB

T9-56
Double MF Switched Socket
With Neon+USB+ Type-C

T9-57
Cooker Unit

T9-58
Double 5 pin MF Switched Socket
With Neon

T9-59
Double 5 pin MF Switched Socket
With Neon+2USB

T9-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T9-61
45A Switch With Neon



T9-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T9-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T9-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T9-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T9-05
Doorbell Switch



T9-06
MF Switched Socket
With Neon



T9-07
MF Switched Socket
With Neon+2USB



T9-08
MF Switched Socket
With Neon+USB+ Type-C



T9-09
15A Switched Socket
With Neon



T9-10
5 pin MF Switched Socket
With Neon



T9-11
13A Switched Socket
With Neon



T9-12
13A Switched Socket
With Neon+2USB



T9-13
13A Switched Socket
With Neon+USB+ Type-C



T9-14
2 Pole Switched Socket



T9-15
4 Pole Switched Socket



T9-16
20A Switch With Neon



T9-17
45A Switch With Neon



T9-18
Two Pole Socket



T9-19
MF Socket



T9-20
13A Socket



T9-21
Four Pole Socket



T9-22
5 pin MF Socket



T9-23
5 pin MF Socket+2USB



T9-24
5 pin MF Socket
+USB+2 Type-C



T9-25
5 pin MF Switched Socket
With Neon+2 USB



T9-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T9-27
USB+Type-C Socket



T9-28
Double USB+Type-C
Socket



T9-29
25A Switch With Neon



T9-30
45A Switch With Neon



T9-31
Germany socket



T9-32
French socket



T9-33
Europe socket



T9-34
Satellite Socket



T9-35
TV Socket



T9-36
TEL Socket
T9-37
Computer Socket



T9-38
TV+TEL Socket



T9-39
TV+ Computer Socket



T9-40
Double Computer Socket



T9-41
Satellite+TV Socket
T9-42
Satellite+Computer Socket

T9-43
Dimmer Switch
T9-44
Speed Control Switch

T9-45
Voice Control Swith
T9-46
Touch Delay Swith

T9-47
Human Body Sensor
Switch

T9-48
Human-induced Foot Lamp

T9-49
86 Blank Plate
T9-62
146 Blank Plate

T9-50
Double 13A Switched Socket
With Neon

T9-51
Double 13A Switched Socket
With Neon+2USB

T9-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T9-53
Double 13A Socket

T9-54
Double MF Switched Socket
With Neon

T9-55
Double MF Switched Socket
With Neon+2USB

T9-56
Double MF Switched Socket
With Neon+USB+ Type-C

T9-57
Cooker Unit

T9-58
Double 5 pin MF Switched Socket
With Neon

T9-59
Double 5 pin MF Switched Socket
With Neon+2USB

T9-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T9-61
45A Switch With Neon

Ultra-thin Skin-sensitive Glass



T10 series

■ Gold ■ Black

Private spaces deserve the best quality light switches,so together with international interior design experts,we have created a key series. In the perfect shape design,it is the modern advanced technology

of the world's top smart home control system manufacturer
Every switch is made to the highest standards Manufacturing, guaranteeing the longest service life.

T10 Gold series

Ultra-thin Skin-sensitive Glass



T10-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T10-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T10-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T10-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T10-05
Doorbell Switch



T10-06
MF Switched Socket
With Neon



T10-07
MF Switched Socket
With Neon+2USB



T10-08
MF Switched Socket
With Neon+USB+ Type-C



T10-09
15A Switched Socket
With Neon



T10-10
5 pin MF Switched Socket
With Neon



T10-11
13A Switched Socket
With Neon



T10-12
13A Switched Socket
With Neon+2USB



T10-13
13A Switched Socket
With Neon+USB+ Type-C



T10-14
2 Pole Switched Socket



T10-15
4 Pole Switched Socket



T10-16
20A Switch With Neon



T10-17
45A Switch With Neon



T10-18
Two Pole Socket



T10-19
MF Socket



T10-20
13A Socket



T10-21
Four Pole Socket



T10-22
5 pin MF Socket



T10-23
5 pin MF Socket+2USB



T10-24
5 pin MF Socket
+USB+2 Type-C



T10-25
5 pin MF Switched Socket
With Neon+2 USB



T10-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T10-27
USB+Type-C Socket



T10-28
Double USB+Type-C
Socket



T10-29
25A Switch With Neon



T10-30
45A Switch With Neon



T10-31
Germany socket



T10-32
French socket



T10-33
Europe socket



T10-34
Satellite Socket



T10-35
TV Socket



T10-36
TEL Socket
T10-37
Computer Socket



T10-38
TV+TEL Socket



T10-39
TV+ Computer Socket



T10-40
Double Computer Socket



T10-41
Satellite+TV Socket
T10-42
Satellite+Computer Socket

T10-43
Dimmer Switch
T10-44
Speed Control Switch

T10-45
Voice Control Swith
T10-46
Touch Delay Swith

T10-47
Human Body Sensor
Switch

T10-48
Human-induced Foot Lamp

T10-49
86 Blank Plate
T10-62
146 Blank Plate

T10-50
Double 13A Switched Socket
With Neon

T10-51
Double 13A Switched Socket
With Neon+2USB

T10-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T10-53
Double 13A Socket

T10-54
Double MF Switched Socket
With Neon

T10-55
Double MF Switched Socket
With Neon+2USB

T10-56
Double MF Switched Socket
With Neon+USB+ Type-C

T10-57
Cooker Unit

T10-58
Double 5 pin MF Switched Socket
With Neon

T10-59
Double 5 pin MF Switched Socket
With Neon+2USB

T10-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T10-61
45A Switch With Neon

T10 | Black series

Ultra-thin Skin-sensitive Glass



T10-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



T10-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



T10-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



T10-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



T10-05
Doorbell Switch



T10-06
MF Switched Socket
With Neon



T10-07
MF Switched Socket
With Neon+2USB



T10-08
MF Switched Socket
With Neon+USB+ Type-C



T10-09
15A Switched Socket
With Neon



T10-10
5 pin MF Switched Socket
With Neon



T10-11
13A Switched Socket
With Neon



T10-12
13A Switched Socket
With Neon+2USB



T10-13
13A Switched Socket
With Neon+USB+ Type-C



T10-14
2 Pole Switched Socket



T10-15
4 Pole Switched Socket



T10-16
20A Switch With Neon



T10-17
45A Switch With Neon



T10-18
Two Pole Socket



T10-19
MF Socket



T10-20
13A Socket



T10-21
Four Pole Socket



T10-22
5 pin MF Socket



T10-23
5 pin MF Socket+2USB



T10-24
5 pin MF Socket
+USB+2 Type-C



T10-25
5 pin MF Switched Socket
With Neon+2 USB



T10-26
5 pin MF Switched Socket
With Neon+USB+Type-C



T10-27
USB+Type-C Socket



T10-28
Double USB+Type-C
Socket



T10-29
25A Switch With Neon



T10-30
45A Switch With Neon

T10 | Black series

SWITCH & SOCKET



T10-31
Germany socket



T10-32
French socket



T10-33
Europe socket



T10-34
Satellite Socket



T10-35
TV Socket



T10-36
TEL Socket
T10-37
Computer Socket



T10-38
TV+TEL Socket



T10-39
TV+ Computer Socket



T10-40
Double Computer Socket



T10-41
Satellite+TV Socket
T10-42
Satellite+Computer Socket

T10-43
Dimmer Switch
T10-44
Speed Control Switch

T10-45
Voice Control Swith
T10-46
Touch Delay Swith

T10-47
Human Body Sensor
Switch

T10-48
Human-induced Foot Lamp

T10-49
86 Blank Plate
T10-62
146 Blank Plate

T10-50
Double 13A Switched Socket
With Neon

T10-51
Double 13A Switched Socket
With Neon+2USB

T10-52
Double 13A Switched Socket
With Neon+USB+ Type-C

T10-53
Double 13A Socket

T10-54
Double MF Switched Socket
With Neon

T10-55
Double MF Switched Socket
With Neon+2USB

T10-56
Double MF Switched Socket
With Neon+USB+ Type-C

T10-57
Cooker Unit

T10-58
Double 5 pin MF Switched Socket
With Neon

T10-59
Double 5 pin MF Switched Socket
With Neon+2USB

T10-60
Double 5 pin MF Switched Socket
With Neon+USB+ Type-C

T10-61
45A Switch With Neon